



Gryphon Garage Doors

Delete and Re-Code TM60 Remotes

1. Stand behind motor, facing garage door.
 2. Unscrew motor casing. Screw is located at back of cover in centre. Casing will hang down.
 3. You will now be able to see the green circuit board.
 3. Press Learn button and hold in for 15 seconds.
- Proceed as below to re-code your remote.

1. Stand behind motor facing garage door.
2. Remove rear light casing – you will see part of the circuit board.
3. Hold 'Learn' button until light at front of motor flashes and release – is found on the right hand side of board (button 2 on diagram below)
4. Press and hold one of the buttons on the handset for 3-4 seconds.

Handset will now be coded in.

If you have any questions – please contact your local office.