




Delete and Recode A45/A60/M50 Remotes

1. Stand behind motor, facing garage door.
2. Unscrew motor casing. Screw is located at back of cover in centre. Casing will hang down.
3. You will now be able to see the green circuit board.
3. Press brown coding chip (see details below on how to locate) and hold in for 15 seconds.
4. Proceed as below to recode your remote.

Coding in Handsets.

1. Stand behind motor, facing garage door.
2. Unscrew motor casing. Screw is located at back of cover in centre. Casing will hang down.
3. You will now be able to see the green circuit board.
4. Coding chip is the small rectangular chip located on the near right hand corner. It has a red light and brown/yellow button on it.



If you have any questions, please do not hesitate to contact your nearest office.